



Cesium-131 Nomogram Monotherapy Prescription Dose 115 Gy

Volume (cc)	Total Activity (U)	Volume (cc)	Total Activity (U)
8	84.4	50	195.3
10	89.7	52	200.6
12	95.0	54	205.9
14	100.3	56	211.1
16	105.5	58	216.4
18	110.8	60	221.7
20	116.1	62	227.0
22	121.4	64	232.3
24	126.7	66	237.5
26	131.9	68	242.8
28	137.2	70	248.1
30	142.5	72	253.4
32	147.8	74	258.7
34	153.1	76	263.9
36	158.3	78	269.2
38	163.6	80	274.5
40	168.9	82	279.8
42	174.2	84	285.1
44	179.5	86	290.3
46	184.7	88	295.6
48	190.0	90	300.9

¹³¹ Cs Seed Strengths	
Prostate Volume	Seed Strength
<25 cc	1.6 U
25-50 cc	1.8U
>50 cc	2.0 U

This nomogram is only intended to estimate the number of seeds to order when using 3D treatment planning software for a real-time implant. Extra seeds may be ordered to allow for any prostate volume change between the initial ultrasound date and the implant date.